



## SINGLE USE ONLY

# Receiving Vaccines: Reading a TagAlert Monitor

### Step 1: Press and hold STOP button!

Press and hold the STOP  button for approximately 5 seconds until an Octagon  icon appears



### Step 2: Identify whether there has been a cold chain breach.



If the arrow is pointing to the green tick, no alarms have been triggered and the delivery is **suitable for use** (Figure 1).

**Figure 1:**  
No alarm has been triggered

Place vaccines in the fridge



If the arrow is pointing to the red cross and there is **one or more** numbers (e.g. 1 & 3 in Figure 2), an alarm has been triggered for your delivery. (Figure 2). **FOLLOW STEPS 3 to 5.**

**Figure 2:**  
Alarms 1 & 3 have been triggered

### Step 3: Quarantine Vaccines

Quarantine the vaccines, ensuring they are stored between 2°C and 8°C, until further notice from the Health Department.

### Step 4: Record the static number/s showing on the TagAlert.

Take a close-up photo of the TagAlert.

### Step 5: Press Start button (a sequence of numbers will follow)

1. Record the number/s that flashes for 4 seconds
2. Record the next number/s that flash for 2 seconds
3. Record the next number/s that display for 2 seconds
4. Proceed to Step 6

### Step 6: Complete your details

When you have recorded the numbers, fill in your details below, and email this sheet, a close-up photo of the TagAlert, and a copy of the packing note/invoice to: [customerservice@onelink.com.au](mailto:customerservice@onelink.com.au)

#### CUSTOMER DETAILS:

Account Name:	<input type="text"/>	Date:	<input type="text"/>
Account Number:	<input type="text"/>	Invoice Number:	<input type="text"/>
Contact Name:	<input type="text"/>	Contact Phone:	<input type="text"/>
Contact Email:	<input type="text"/>		